

About This Manual



WWW.AKUVOX.COM



Akuvox Access Control Administrator Guide

Thank you for choosing the Akuvox A03 access control terminal. This manual is intended for administrators who need to properly configure the access control terminal. This manual is written based on firmware version 103.30.10.204, and it provides all the configurations for the functions and features of the A03 access control terminal. Please visit the Akuvox forum or consult technical support for any new information or the latest firmware.

Product Overview

Akuvox Access control terminal A03 incorporates a door controller and an RFID reader in one standalone device, thus saving your solution costs. It is equipped with a card reader (125kHz and 13.5MHz) which is currently capable of handling a majority of cards in wide use. It is designed to provide you with greater flexibility and security than traditional access control systems. A03 access control terminal applies to residential buildings, office buildings, and their complex.

Changelog

What's new in version 103.30.10.204:

The new features require the device to be connected to the SmartPlus Cloud:

- Support the lockdown function;
- Support the muster report feature;
- Support updating [Wiegand](#) and [RS485 settings](#) from the cloud;
- Support identifying license plates and UHF cards for smart parking;
- Support selecting the input(s) connected to exit buttons on the cloud;
- Support reporting logs of tamper alarm and break-in alarm to the cloud;
- Support reporting logs of door-opening by pressing an exit button to the cloud.


Click [here](#) to view the changelog of the device's previous versions.

Model Specification

| Model | A03 |
|--------------------|---|
| RFID card reader | 13.56MHz & 125KHz |
| Relay out | 1 |
| Inputs | 2 |
| Wiegand | ✓ |
| Speaker | 1 |
| Tamper proof alarm | ✓ |
| Ethernet port | RJ45, 10/100Mbps adaptive 802.3af power-over-Ethernet/12v DC connector (if not using poE) |
| Wi-Fi | X |
| Bluetooth | ✓ |


Introduction to Configuration Menu

- **Status:** This section gives you basic information such as product information, network information, and access log management.
- **Network:** This section covers LAN port settings.
- **Access Control:** This section covers relay, input, web relay, card settings, keypad settings, etc.
- **Directory:** This section includes access schedule management and user management.
- **Device:** This section includes light, Wiegand, lift control, and audio settings.
- **Setting:** This section deals with relay schedule, security notification settings, web relay, time, action, and HTTP API settings.
- **System:** This section covers firmware upgrade, device reset, reboot, configuration file auto-provisioning, system log and PCAP, password modification as well as device backup.



Access the Device

Before configuring Akuvox A03, please make sure the device is installed correctly and connects to a normal network. Using the Akuvox IP scanner tool to search the device IP address in the same LAN. Then use the IP address to log in to the web browser by user name and password **admin** and **admin**.




Note

- Download IP scanner:
<https://knowledge.akuvox.com/docs/akuvox-ip-scanner?highlight=IP>
- See detailed guide:
<https://knowledge.akuvox.com/v1/docs/en/how-to-obtain-ip-address-via-ip-scanner?highlight=IP%20Scanner>
- Google Chrome browser is strongly recommended.
- Please be case-sensitive to the user names and passwords entered.

You can also obtain the IP by pressing the **Reset** button on the device's back. The device will announce the IP address.

You can set up the IP announcement loop times on the **Device > Audio** interface.



IP Announcement

Loop Times

1

Time and Language

Time

The time settings on the web interface allow you to configure the NTP server address for automatic time and date synchronization. Once a time zone is selected, the device will notify the NTP server of the chosen time zone, enabling it to synchronize the time zone settings on your device.

Set up time on the **Setting > Time** interface.

NTP

Automatic Date&Time Enabled

☒

Time Zone

GMT+0:00 London ▼

Preferred Server

0.pool.ntp.org

Alternate Server

1.pool.ntp.org

Update Interval

3600

(≥ 3600Sec)

Current Time

03:48:15

- **Automatic Date&Time Enabled:** If enabled, the device will update the time automatically via the NTP server (**Network Time Protocol**). Disable it if you want to set up the time manually.
- **Date/Time:** Set the date and time for the device manually when you disable the automatic date and time service.
- **Time Zone:** Select the specific time zone based on where the device is used. The default time zone is GMT+0:00.
- **Preferred Server:** Enter the primary NTP server address you want to update the time with. The default NPT server address is 0.pool.ntp.org
- **Alternate Server:** Enter the NPT server address for backup.
- **Update Interval:** Set the time update interval. For example, if you set it as 3600s, then the device will send a request to the NPT server for the time update once every 3600 seconds.
- **Current Time:** Display the current device time.

Language

You can switch the web language by selecting the language in the upper right corner.

The following languages are supported: English, Simplified Chinese, Spanish, Dutch, French, and German.



LED Setting

LED Setting on Card Reader Area

You can enable or disable the LED lighting on the card reader area. You can also set a specific time to turn on the light.

To set it up, go to **Device > Light** interface.

| Light Of Swiping Card Area | | |
|-----------------------------|--|--------|
| Backlight Intensity | <input type="text" value="1"/> | (1~5) |
| Backlight Enabled | <input checked="" type="checkbox"/> | |
| Start Time - End Time(Hour) | <input type="text" value="18"/> - <input type="text" value="6"/> | (0~23) |

- **Backlight Intensity:** Adjust the backlight intensity, the bigger the value, the brighter the backlight.
- **Start Time - End Time (Hour):** Select the time span for the LED lighting to be valid, e.g., if the time span is from 18-22, it means the LED light will stay on during the time span from 6:00 pm to 10:00 pm in one day (24 hours).

Volume and Tone

Volume and tone configuration include tamper alarm and prompt volume. Besides, you can upload door-opening ringtones.

To set it up, go to **Device > Audio** interface.

| Volume Control | | |
|---------------------|--------------------------------|--------|
| Tamper Alarm Volume | <input type="text" value="8"/> | (1~15) |
| Prompt Volume | <input type="text" value="8"/> | (0~15) |

- **Tamper Alarm:** Set the volume when the tamper alarm is triggered. The default volume is 8.
- **Prompt Volume:** Set the voice prompt volume. The default volume is 8.

Upload Open Door Tone

You can upload the tone for open door failure and success on the device web interface.

To upload the tones, go to **Device > Audio > Open Door Tone Setting** interface. Enable the open door tone before uploading the file.

| Open Door Tone Setting | | |
|-------------------------------|---------------------------------------|--------------------------------------|
| Open Door Tone Enabled | <input checked="" type="checkbox"/> | |
| Open Door Succeed Tone Upload | <input type="button" value="Import"/> | <input type="button" value="Reset"/> |
| Open Door Failed Tone Upload | <input type="button" value="Import"/> | <input type="button" value="Reset"/> |

Note

File Format: wav, size: < 200KB, pcm(sample rate: 16000, bits: 16, mono)/pcma/pcmu

Network Setting

To ensure normal functioning, make sure that the device has its IP address set correctly or obtained automatically from the DHCP server.

To set it up, go to **Network > Basic** interface.

LAN Port

Type

☐ DHCP
 ☒ Static IP

IP Address

Subnet Mask

Default Gateway

Preferred DNS Server

Alternate DNS Server

- **DHCP:** DHCP mode is the default network connection. If the DHCP mode is selected, the access control terminal will be assigned by the DHCP server with IP address, subnet mask, default gateway, and DNS server address automatically.
- **Static IP:** When static IP mode is selected, the IP address, subnet mask, default gateway, and DNS server address should be configured according to the network environment.
- **IP Address:** Set up the IP address when the static IP mode is selected.
- **Subnet Mask:** Set up the subnet mask according to the actual network environment.
- **Default Gateway:** Set up the correct gateway according to the IP address.
- **Preferred/Alternate DNS Server:** Set up the preferred or alternate Domain Name Server(DNS) server according to the actual network environment. The preferred DNS server is the primary server while the alternate DNS server is the secondary one. The secondary server is for backup.

SNMP Setting

Simple Network Management Protocol(**SNMP**) is a protocol for managing IP network devices. It allows network administrators to monitor devices and receive alerts for attention-worthy conditions. SNMP provides variables describing system configuration, organized in hierarchies and described by Management Information Bases (MIBs).

To set it up, go to **Network > Advanced** interface.

| SNMP | |
|------------|-----------------------------------|
| Enabled | <input type="checkbox"/> |
| Port | <input type="text"/> (1024~65535) |
| Trusted IP | <input type="text"/> |

- **Port:** Set a specific port for the data transmission from 1024-65535.
- **Trusted IP:** Enter the third-party IP address.

Relay Settings

You can configure the relay switch(es) for door access on the web interface.

Local Relay

A local relay is an external unit that is physically nearby and directly connected to the intercom device. It allows the intercom system to trigger actions, such as unlocking a door, based on user input or authorization.

To set up the relay, go to **Access Control > Relay > Relay** interface.

Relay

| | |
|--------------------|--|
| Mode | Monostable ▼ |
| Trigger Delay(Sec) | 0 ▼ |
| Hold Delay(Sec) | 5 ▼ |
| Action To Execute | <input type="checkbox"/> Email <input type="checkbox"/> HTTP |
| HTTP URL | |
| Type | Default State ▼ |
| Relay Status | Low |
| Relay Name | Relay |

- **Mode:** Specify the conditions for automatically resetting the relay status.
 - **Monostable:** The relay status resets automatically within the relay delay time after activation.
 - **Bistable:** The relay status resets upon triggering the relay again.
- **Trigger Delay(Sec):** Set the delay time before the relay triggers. For example, if set to 5 seconds, the relay activates 5 seconds after pressing the Unlock button.
- **Hold Delay(Sec):** Determine how long the relay stays activated. For example, if set to 5 seconds, the relay remains to be opened for 5 seconds before closing.

- **Action to Execute:** Check the action to be executed when the relay is triggered.
 - **HTTP:** When triggered, the HTTP message can be captured and displayed in the corresponding packets. To utilize this feature, enable the HTTP server and enter the message content in the designated box below.
 - **Email:** Send a screenshot to the preconfigured Email address.
- **HTTP URL:** Enter the HTTP message if selecting HTTP as the action to execute. The format is http://HTTP server's IP/Message content.
- **Type:** Determine the interpretation of the Relay Status regarding the state of the door:
 - **Default State:** A "Low" status in the Relay Status field indicates that the door is closed, while "High" indicates that it is opened.
 - **Invert State:** A "Low" status in the Relay Status field indicates an opened door, while "High" indicates a closed one.
- **Relay Status:** Indicate the states of the relay, which are normally opened and closed. By default, it shows low for normally closed(NC) and high for Normally Open(NO).
- **Relay Name:** Assign a distinct name for identification purposes.

Note

External devices connected to the relay require separate power adapters.

Security Relay

The Security Relay, known as Akuvox SR01, is a product designed to bolster access security by preventing unauthorized forced entry attempts. Installed inside the door, it directly governs the door opening mechanism, ensuring that the door remains secure even in the event of damage to the device.



Click [here](#) to view how to set up the security relay.

To set it up, go to **Access Control > Relay > Security Relay** interface.

| Security Relay | |
|-------------------------------------|---|
| Relay ID | Security Relay A |
| Connect Type | Relay A Power Output |
| Trigger Delay(Sec) | <input type="text" value="0"/> |
| Hold Delay(Sec) | <input type="text" value="5"/> |
| Relay Name | <input type="text" value="Security Relay A"/> |
| Enabled | <input type="checkbox"/> |
| <input type="button" value="Test"/> | |

- **Relay ID:** The specific relay for door access.
- **Connect Type:** The security relay connects to the device using Power Output by default.
- **Trigger Delay(Sec):** Set the delay time before the relay triggers. For example, if set to 5 seconds, the relay activates 5 seconds after pressing the Unlock button.
- **Hold Delay(Sec):** Determine how long the relay stays activated. For example, if set to 5 seconds, the relay remains to be opened for 5 seconds before closing.
- **Relay Name:** Name the security relay. The name can be displayed in door opening logs. When connecting to the SmartPlus Cloud, the Cloud server will automatically assign the relay name.

Web Relay

A web relay has a built-in web server and can be controlled via the Internet or a local network. The device can use a web relay to either control a local relay, or a remote relay somewhere else on the network.



Click [here](#) to view how to set up web relay.

To set it up, go to **Access Control > Web Relay** interface.

Web Relay

Type

Disabled ▼

IP Address

Username

Password

Web Relay Action Setting

| Action ID | Web Relay Action |
|-----------|------------------|
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |

- **Type:** Determine the type of relay activated when employing door access methods for entry.
 - **Disabled:** Only activate the local relay.
 - **Web Relay:** Only activate the web relay.
 - **Local Relay+Web Relay:** Activate both the local relay and web relay. Typically, the local relay is triggered first, followed by the web relay to execute their pre-configured actions.
- **IP Address:** The web relay IP address provided by the web relay manufacturer.
- **Username:** The user name provided by the web relay manufacturer.

- **Password:** The manufacturer-provided authentication key for the web relay. Authentication occurs via HTTP. Leaving the Password field blank indicates non-use of HTTP authentication. You can define the password using HTTP GET in the Web Relay Action field.
- **Web Relay Action:** Configure the actions to be performed by the web relay upon triggering. Enter the manufacturer-provided URLs for various actions, with up to 50 commands.

NOTE

If the URL includes full HTTP content (e.g., `http://admin:admin@192.168.1.2/state.xml?relayState=2`), it doesn't rely on the IP address that you entered above. However, if the URL is simpler (e.g., `"state.xml?relayState=2"`), the relay uses the entered IP address.


Door Access Schedule Management

Door Access Schedule

A door access schedule lets you decide who can open the door and when. It applies to both individuals and groups, ensuring that users within the schedule can only open the door using the authorized method during designated time periods.

Create Door Access Schedule

To create a door access schedule, go to the **Setting > Schedule** interface.




Schedule

ALL + Add Import Export

| <input type="checkbox"/> | Index | Schedule ID | Source | Mode | Name | Date | Day Of Week | Time | Edit |
|--------------------------|-------|-------------|--------|-------|--------|------|-------------|-------------|------|
| <input type="checkbox"/> | 1 | 1001 | Local | Daily | Always | | | 00:00-23:59 | |
| <input type="checkbox"/> | 2 | 1002 | Local | Daily | Never | | | 00:00-00:00 | |

Selected:0/2 Delete Delete All Total:2 Prev 1/1 Next Go To Page 1 Go

Click **+Add** to create a schedule.



Schedule

ALL + Add Import Export

| <input type="checkbox"/> | Index | Schedule ID | Source | Mode | Name | Date | Day Of Week | Time | Edit |
|--------------------------|-------|-------------|--------|-------|--------|------|-------------|-------------------|------|
| <input type="checkbox"/> | 1 | 1001 | Local | Daily | Always | | | 00:00-23:59 | |
| <input type="checkbox"/> | 2 | 1002 | Local | Daily | Never | | | 00:00-00:00 | |
| <input type="checkbox"/> | 3 | 16803 | | | | | | 00:00:00-03:59:59 | |
| <input type="checkbox"/> | 4 | 18770 | | | | | | 00:00:00-03:59:59 | |
| <input type="checkbox"/> | 5 | 18771 | | | | | | 00:00:00-03:59:59 | |

Selected:0/5 Delete

Add Schedule ×

Name

Mode

Date Range -

Day Of Week ☒ Monday ☒ Tuesday ☒ Wednesday ☒ Thursday ☒ Friday ☒ Saturday ☒ Sunday ☐ Check All

Date Time -

Holiday Exemption ☐

Cancel Submit


- **Name:** Name the schedule.
- **Mode:**
 - **Normal:** Set the schedule based on the month, week, and day. It is used for a long period schedule.

- **Weekly:** Set the schedule based on the week.
- **Daily:** Set the schedule based on 24 hours a day.
- **Holiday Exemption:** The [holiday schedule](#) has higher priority over the access schedule which limits users from opening doors. If users want to open doors during holidays within the access schedule, you need to check this option.

Import and Export Door Access Schedule

You can create door access schedules one by one or in bulk. You can export the current schedule file, edit it or add more schedules following the format, and import the new file to the desired devices. This helps you manage your door access schedules easily.

To set it up, go to the **Setting > Schedule** interface. The export file is in **TGZ** format. The import file should be in **XML** format.




The screenshot shows the 'Schedule' interface. At the top, there is a dropdown menu currently set to 'ALL'. Below this, there are three blue buttons: '+ Add', 'Import', and 'Export'.

Relay Schedule

The relay schedule allows you to set a specific relay to always open at a certain time. This is helpful for situations like keeping the gate open after school or keeping the door open during work hours.

To set it up, go to **Access Control > Relay > Relay Schedule** interface.



The screenshot shows the 'Relay Schedule' interface. It includes the following elements:

- Relay ID:** A dropdown menu currently set to 'RelayA'.
- Schedule Enabled:** A checkbox that is checked (blue square).
- Activation Required:** A checkbox that is unchecked (white square).
- Items List:** A table with two columns: 'Unselected' and 'Selected'.

| Unselected | Selected |
|---|----------|
| 2 items | 0 item |
| <input type="checkbox"/> 1001:Always <input type="checkbox"/> 1002:Never | No Data |

- **Relay ID:** Specify the relay you need to set up.

- **Activation Required:** It means only after the relay is triggered successfully for the first time, can it be triggered by device-supported access methods later.
- **Schedule:** Assign particular door access schedules to the chosen relay. Simply move them to the Selected Schedules box.

For instructions on creating schedules, kindly consult the [Create Door Access Schedule](#) section.

Holiday Schedule

You can define the holidays when users cannot open doors to enhance access control security. You can also set the Working Hours to allow authorized users to open doors.

Configure it on the web **Setting > Holiday** interface. Click **+Add** to add a holiday and click **+Clear** to clear the selection of all dates.


Holiday

ALL

+ Add

Import

Export

| <input type="checkbox"/> | Index | Source | Holiday Name | Repeat By Year | Operation |
|--|-------|--------|--------------|----------------|-----------|
| <div> No Data</div> | | | | | |

Selected:0/0

Delete

Delete All

Total:0

Prev

1/1

Next

Go To Page 1

Go

Calendar

Holiday Name

Repeat By Year

☐

Year

2024

Working Hours

☐

Clear

January

Mo Tu We Th Fr Sa Su

1 2 3 4 5 6 7

8 9 10 11 12 13 14

15 16 17 18 19 20 21

22 23 24 25 26 27 28

29 30 31 1 2 3 4

February

Mo Tu We Th Fr Sa Su

1 2 3 4

5 6 7 8 9 10 11

12 13 14 15 16 17 18

19 20 21 22 23 24 25

26 27 28 29 1 2 3

March

Mo Tu We Th Fr Sa Su

1 2 3

4 5 6 7 8 9 10

11 12 13 14 15 16 17

18 19 20 21 22 23 24

25 26 27 28 29 30 31

April

Mo Tu We Th Fr Sa Su

1 2 3 4 5 6 7

8 9 10 11 12 13 14

15 16 17 18 19 20 21

22 23 24 25 26 27 28

29 30 1 2 3 4 5

May

Mo Tu We Th Fr Sa Su

1 2 3 4 5

6 7 8 9 10 11 12

13 14 15 16 17 18 19

20 21 22 23 24 25 26

27 28 29 30 31 1 2

June

Mo Tu We Th Fr Sa Su

1 2

3 4 5 6 7 8 9

10 11 12 13 14 15 16

17 18 19 20 21 22 23

24 25 26 27 28 29 30

1 2 3 4 5 6 7

July

August

September

October

November

December

- **Holiday Name:** Name the schedule.
- **Repeat By Year:** Set whether to repeat the schedule every year.
- **Year:** Select the year.
- **Working Hours:** During working hours, users are allowed to open doors with their credentials.

You can also import and export schedule files on the same interface. The file exported is in TGZ format. The imported file should be in XML format.

Holiday

ALL

+ Add

Import

Export

Door-opening Configuration

User-specific Access Methods

The private PIN code, RF card, and Bluetooth setting should be assigned to a particular user for door opening.

When adding a user, you can also customize settings such as defining the door access schedule to determine when the code is valid and specifying which relay to open.

To add a user, go to **Directory > User** interface and Click **+Add**.

User

ALL

Search

Reset

+ Add

Import

Export

| | Index | Source | User ID | Name | PIN | RF Card | Floor No. | Web Relay | Schedule-Relay | Edit |
|--------------------------|-------|--------|---------|------|-----|----------|-----------|-----------|----------------|------|
| <input type="checkbox"/> | 1 | Local | 1 | iris | | 3CF83AC1 | None | 0 | 1001-1 | |
| <input type="checkbox"/> | 2 | Local | 2 | Judy | | FFB59828 | None | 0 | 1001-1 | |

Selected:0/2

Delete

Delete All

Total:2

Prev

1/1

Next

Go To Page

1

Go

User Info

User ID

3

Name

- **User ID:** The unique identification number assigned to the user.
- **Name:** The name of this user.

Unlock by Private PIN Code

The device can be connected to an external keypad. Users can open doors by entering their private PINs on the keypad.

On the **Directory > User > +Add** interface, scroll to the **PIN** section.

PIN

Code

- **Code:** Set a 2-8 digit PIN code solely for the use of this user. Each user can only be assigned a single PIN code.

Unlock by RF Card/Bkey

On the **Directory > User > +Add** interface, scroll to the **RF Card** section.

RF Card & Bkey

Code

+ Obtain

Add

If you want to add Bkey, please make sure the BLE function is set to Enable.

- **Code:** The card code or Bkey code that the card reader reads.

Note:

- Click [here](#) to view the detailed steps of configuring Bkey.
- Each user can have a maximum of 5 cards added.
- The device allows to add 20,000 users.
- RF cards operating at 13.56 MHz and 125 KHz frequencies are compatible with the device for access.

RF Card Code Format

To integrate the RF card door access with the third-party intercom system, you need to match the RF card code format with the one used by the third-party system.

To set it up, go to **Access Control > Card Setting > RFID** interface.

RFID

IC Card Display Mode

8HN

ID Card Display Mode

8HN

ID Card Reading Bytes

4 Bytes

- **IC/ID Card Display Mode:** Set the card number format from the provided options. The default format in the device is 8HN.

- **ID Card Reading Bytes:** Select the number of bytes read from the ID card, 3 bytes or 4 bytes.

Unlock by License Plate

Akuvox offers two main ways to identify vehicles and open gates.

- Use a [third-party LPR\(License Plate Recognition\) camera](#) to recognize the license plate of the vehicle.
- Use the [Akuvox long-range card reader ACR-CPR12](#) to recognize the UHF card attached to the vehicle's windshield.

To assign the license plate to a user, find the **License Plate** part on the **Directory > User > +Add** interface.

License Plate

| | | |
|------|------------------------------------|----------|
| Code | <input type="text"/> | Duration |
| | <input type="button" value="Add"/> | |

- **Add:** A user can have up to 5 license plates.
- **Duration:** Enable/disable Long-term Vehicle. It is enabled by default. If disabled, specify when the vehicle can enter or exit the parking lot.


Unlock by Bluetooth

A03 supports opening the door via Bluetooth-enabled My MobileKey or SmartPlus App. Users can either open the door with the apps in their pockets or wave their phones towards the device as they get closer to the door.

Unlock via My MobileKey

On the **Directory > User > +Add** interface, scroll to the **BLE Setting** section.

BLE Setting

| | | | |
|---------------------|----------------------|---|---|
| Authentication Code | <input type="text"/> | <input type="button" value="Generate"/> |  |
| Status | Unpaired | | |
| Pairing Valid Until | N/A | | |

- **Authentication Code:** Click **Generate** to generate a 6-digit verification code.

You can set up the pairing valid time within which users need to finish the pairing.


To set it up, go to **Access Control > BLE > BLE** interface.

BLE

Enabled ☒

Enable Hands Free Mode ☐

Trigger Distance ?

BKey Trigger Signal  about 5 meters ?

Unlock Interval For Same User(Sec) (5~900Sec) ?

Unlock Interval For Different User(S... (5~900Sec) ?

Authentication Code Valid Time

Note

Click [here](#) to see the configuration steps.

Unlock via SmartPlus App

To open the door via the SmartPlus App, the device should be connected to the SmartPlus Cloud.


To set up Bluetooth unlock, go to **Access Control > BLE > BLE** interface.

BLE

Enabled ☒

Enable Hands Free Mode ☐

Trigger Distance ?

BKey Trigger Signal  about 5 meters ?

Unlock Interval For Same User(Sec) (5~900Sec) ?

Unlock Interval For Different User(S... (5~900Sec) ?

Authentication Code Valid Time

- **Enable Hands Free Mode:** If enabled, users can gain door access hands-free. If disabled, users have to wave their hands near the device to open doors.
- **Trigger Distance:** Set the triggering distance of the Bluetooth for the door access. You select Within 1 Meter, Within 2 Meters, and Within 3 Meters. The trigger distance is 3 meters maximum.
- **Bkey Trigger Signal:** There are three ranges that determine the Bkey trigger distance.
- **Unlock Interval For Same User(Sec):** Set the time interval between consecutive Bluetooth door access attempts for the same user.
- **Unlock Interval For Different User(Sec):** Set the time interval between consecutive Bluetooth door access attempts for different users.

Note

To learn about detailed configuration steps of different Bluetooth-based access methods, you can click the following articles.

- [Unlock by Bluetooth via My MobileKey App.](#)
- [Unlock by Bluetooth via SmartPlus App.](#)
- [Open the Door via Bkey.](#)

Device Info Setting

You can customize the device name and ID for convenient Bluetooth pairing.

To set it up, go to **Access Control > BLE > Device Info Settings** interface.

| Device Info Settings | |
|----------------------|----------------------------------|
| Device Name | <input type="text" value="A03"/> |
| Device ID | <input type="text"/> |

- **Device Name:** Limited to 1-63 numbers or characters.
- **Device ID:** Limited to 1-12 numbers or characters.

Movement Detection Setting

This feature only works for Bluetooth-based door opening via the My Mobilekey App. When enabled, users cannot open the door without shaking their mobile phones.

Enable the function on the **Access Control > BLE > Movement Detection** interface.

| Movement Detection | |
|--------------------|--------------------------|
| Enabled | <input type="checkbox"/> |

Access Setting

You can customize access settings such as defining the door access schedule to determine when the code is valid and specifying which relay to open.

On the **Directory > User > +Add** interface, scroll to the **Access Setting** section.

| Access Setting | |
|----------------|--|
| Relay | <input checked="" type="checkbox"/> RelayA |
| Security Relay | <input type="checkbox"/> Security Relay A |
| Floor No. | <input type="text" value="None x"/> |
| Web Relay | <input type="text" value="0"/> |
| HTTP URL | <input type="text"/> |
| | <input type="button" value="Add"/> |
| Schedule | <div> <div> 1 item <input type="checkbox"/> 1002:Never </div> <div>Unselected</div> </div> <div> <div> 1 item <input type="checkbox"/> 1001:Always </div> <div>Selected</div> </div> |

- **Relay:** Specify the relay(s) to be unlocked using the door opening methods assigned to the user.
- **Security Relay:** Select the security relay that you've configured on the [Security Relay](#) interface.
- **Floor No. :** Specify the accessible floor(s) to the user via the [elevator](#).
- **Web Relay:** Specify the ID of web relay action commands that you've configured on the [Web Relay](#) interface. A default value of 0 indicates that the web relay will not be triggered.

- **HTTP URL:** Enter the HTTP message if you want to carry out an HTTP action. The format is http://HTTP server's IP/Message content.
- **Schedule:** Grant the user access to open designated doors during preset periods by relocating the desired schedule(s) from the left box to the right one. Besides custom schedules, there are 2 default options:
 - **Always:** Allows door opening without limitations on door open counts during the valid period.
 - **Never:** Prohibits door opening.

Import/Export User Data

The door phone supports User Data of access control to be shared among Akuvox door phones through import and export while you can also export the facial data out of the door phone and then import it to a third-party device.

Click [here](#) to view how to import and export user data between Akuvox door phones.

To set it up, go to the **Directory > User** interface.

User

| | Index | Source | User ID | Name | PIN | RF Card | Floor No. | Web Relay | BLE Status | Schedule-Relay | Edit |
|--------------------------|-------|--------|---------|------|-----|---------|-----------|-----------|------------|----------------|------|
| <input type="checkbox"/> | | | | | | | | | | | |

Note

For the import file:

- Format:.tgz/.xml, size: < 2.8MB (Each .xml file)
- Format:.csv, size: < 18MB

The file is exported in the XML or CSV format.

NFC and Felica Card Setting

Set the device to support NFC and Felica cards on the device before they can be used.

To set it up, go to **Access Control > Card Setting > Contactless Smart Card** interface.

| Contactless Smart Card | |
|------------------------|------------|
| Enabled | Disabled ▼ |

- **Enabled:** Select NFC or Felica from the list.
- **Felica Reading Format:** When Felica is selected, set the card reading format between 8 Bytes and 16 Bytes. The default is 16 Bytes.

Note

The NFC feature is not available on iPhones.

Mifare Card Encryption

The device can encrypt Mifare cards for greater security. When this feature is enabled, it reads the data in the cards' designated sectors and blocks, not the UID.

To set it up, go to **Access Control > Card Setting > Contactless Smart Card** interface.

| Contactless Smart Card | |
|------------------------|----------|
| Enabled | Mifare ▼ |
| Sector/Block | / |
| Block Key | |


- **Enabled:** The device supports Mifare Classic, Mifare Desfire, and Mifare Plus.
- **Classic:**
 - **Sector/Block:** Specify the location where encrypted card data is stored. A Mifare card has 16 sectors (0 to 15), and each sector has 4 blocks (0 to 3).
 - **Block Key:** Set a password to access the data stored in the predefined sector/block.
- **Plus:** There are three choices. The device can read the encrypted data in SL1 and SL3.
 - **Block:** The block number where the encrypted data is located.

- **SL3:** The key number within 32 bits.
- **DESFire:**
 - **App ID:** A 6-digit hexadecimal number
 - **File ID:** The ID of the encrypted file of the app, which can be a number from 0 to 31.
 - **Crypto:** The encryption method, either AES or DES.
 - **Key:** The file key.
 - **Key Index:** The index number for the key, which can be a number from 0 to 11.

Unlock by HTTP Command

You can unlock the door remotely without approaching the device physically for door entry by typing in the created HTTP command (URL) on the web browser to trigger the relay when you are not available by the door for door entry.

To set it up, go to **Access Control > Relay > Open Relay Via HTTP** interface.



Open Relay Via HTTP

Enabled ☒

Username

Password

- **Username:** Set a username for authentication in HTTP command URLs.
- **Password:** Set a password for authentication in HTTP command URLs.

Tip:

Here is an HTTP command URL example for relay triggering.

Device's IP
http://192.168.35.127/fcgi/do? action=OpenDoor&

Preset credentials for authentication
UserName=admin&Password=12345&


ID of Relay to be triggered
DoorNum=1

Unlock by Exit Button

When users need to open the door from inside by pressing the Exit button, you need to set up the Input terminal that matches the Exit button to activate the relay for the door access.

Click [here](#) to watch the instruction video.

To set it up, go to **Access Control > Input** interface.



The screenshot shows the 'Input A' configuration page. It has a title bar 'Input A'. Below it, there are several settings:

- Enabled:** A checkbox that is checked.
- Trigger Electrical Level:** A dropdown menu set to 'Low'.
- Action To Execute:** Two checkboxes, 'Email' and 'HTTP', both of which are unchecked.
- HTTP URL:** A text input field that is currently empty.
- Action Delay:** A text input field set to '0', with a note '(0~300Sec)' to its right.
- Action Delay Mode:** A dropdown menu set to 'Unconditional Execution'.
- Execute Relay:** A dropdown menu set to 'None'.
- Alarm Door Opened:** An unchecked checkbox.
- Break-in Intrusion:** An unchecked checkbox.
- Door Status:** A dropdown menu set to 'High'.

- **Enabled:** To use a specific input interface.
- **Trigger Electrical Level:** Set the input interface to trigger at low or high electrical level.
- **Action To Execute:** Set the desired actions that occur when the specific Input interface is triggered.
 - **Email:** Send a screenshot to the preconfigured [Email address](#).
 - **HTTP:** When triggered, the HTTP message can be captured and displayed in the corresponding packets. To utilize this feature, enable the HTTP server and enter the message content in the designated box below.
- **HTTP URL:** Enter the HTTP message if selecting HTTP as the action to execute. The format is [http://HTTP server's IP/Message content](#).
- **Action Delay:** Specify how many seconds to delay executing the preconfigured actions.
- **Action Delay Mode:**
 - **Unconditional Execution:** The action will be carried out when the input is triggered.

- **Execute If Input Still Triggered:** The action will be carried out when the input stays triggered. For example, if the door stays open after triggering input, an action such as an email will be sent to notify the receiver.
- **Execute Relay:** Specify the relay to be triggered by the actions.
- **Alarm Door Opened:** If enabled, when the door-opening time exceeds a limit, an alarm will be triggered.
 - **Door Opened Timeout:** The door-opening time limit.
- **Door Opened Timeout:** Set the time limit for the door to stay open.
- **Break-in Intrusion:** Activate an alarm when the door is forcibly or illegally opened. Only by checking off this option can the alarm be turned off once triggered. Click [here](#) to learn more information about this feature.
- **Door Status:** Display the status of the input signal.

Security

Tamper Alarm

The tamper alarm function prevents anyone from removing the device without permission. Akuvox devices support two types of tamper proof: gravity detection and button status detection.

Click [here](#) to view which type is supported by the device and learn the function details.

To set it up, go to **System > Security > Tamper Alarm** interface.

| Tamper Alarm | |
|--------------------------|---|
| Enabled | <input type="checkbox"/> |
| Gravity Sensor Threshold | <input type="text" value="32"/> (0~127) |

- **Gravity Sensor Threshold:** The threshold for gravity sensory sensitivity. The lower the value is, the more sensitive the sensor will be. It is 32 by default.

Security Notification

Email Notification

Set up email notifications to receive screenshots of unusual motion from the device.

Go to **Setting > Action > Email Notification** interface.

Email Notification

| | |
|--------------------------|---|
| Sender's Email Address | <input type="text"/> |
| Sender's Email Name | <input type="text"/> |
| Receiver's Email Address | <input type="text"/> |
| Receiver's Email Name | <input type="text"/> |
| SMTP Server Address | <input type="text"/> |
| Port | <input type="text"/> |
| SMTP User Name | <input type="text"/> |
| SMTP Password | <input type="password"/> |
| Email Subject | <input type="text"/> |
| Email Content | <input type="text"/> |
| Email Test | <input type="button" value="Test Email"/> |

Action URL

You can use the device to send specific HTTP URL commands to the HTTP server for certain actions. These actions will be triggered when the relay status, input status, PIN code, or RF card access changes.

Akuvox Action URL:

| No | Event | Parameter format | Example |
|----|------------------------|------------------|---|
| 1 | Relay Triggered | \$relay1 status | Http://server ip/relaytrigger=\$relay1 status |
| 2 | Relay Closed | \$relay1 status | Http://server ip/relayclose=\$relay1 status |
| 3 | Input Triggered | \$input1 status | Http://server ip/inputtrigger=\$input1 status |
| 4 | Input Closed | \$input1 status | Http://server ip/inputclose=\$input1 status |
| 5 | Valid Card Entered | \$card_sn | Http://server ip/validcard=\$card_sn |
| 6 | Invalid Card Entered | \$card_sn | Http://server ip/invalidcard=\$card_sn |
| 7 | Tamper Alarm Triggered | \$alarm status | Http://server ip/tampertrigger=\$alarm status |

For example: [http://192.168.16.118/help.xml?mac=\\$mac:ip=\\$ip:model=\\$model:firmware=\\$firmware:card_sn=\\$card_sn](http://192.168.16.118/help.xml?mac=$mac:ip=$ip:model=$model:firmware=$firmware:card_sn=$card_sn)

To set it up, go to **Setting > Action URL** interface.

Action URL

| | |
|------------------------|--|
| Enabled | <input type="checkbox"/> |
| Username | <input type="text"/> |
| Password | <input type="password" value="....."/> |
| Relay Triggered | <input type="text"/> |
| Relay Closed | <input type="text"/> |
| InputA Triggered | <input type="text"/> |
| InputB Triggered | <input type="text"/> |
| InputA Closed | <input type="text"/> |
| InputB Closed | <input type="text"/> |
| Valid Card Entered | <input type="text"/> |
| Invalid Card Entered | <input type="text"/> |
| Tamper Alarm Triggered | <input type="text"/> |

Anti-passback Mode

This anti-passback mode restricts users from entering the door by following others.

Set it up on the **Directory > User** interface.

Anti-passback Mode

| | |
|------|-----------------------------------|
| Mode | <input type="text" value="None"/> |
|------|-----------------------------------|

- **Mode:** Select Entry or Exit to enable the feature. For example, if the user follows someone else through the door, the next time he/she cannot swipe his/her card to pass the Entry/Exit door.

Real-Time Monitoring

When the device is connected to SmartPlus Cloud or ACMS, the door status can be displayed on the SmartPlus platform or ACMS.

To set it up, go to **System > Security > Real-Time Monitoring** interface.

| Real-Time Monitoring | |
|----------------------|--------|
| Apply Setting To | None ▼ |

- **Apply Setting To:**
 - **None:** Not display door status.
 - **Input:** the door is opened by triggering input.
 - **Relay:** the door is opened by triggering the relay.

Note

Click [here](#) to see the detailed configuration steps.

Emergency Action

This feature works with Akuvox SmartPlus Cloud. It keeps the door open when an emergency happens.

To set it up, go to **System > Security > Emergency Action** interface.

| Emergency Action | |
|------------------|---|
| Apply Setting To | <input type="checkbox"/> Input A <input type="checkbox"/> Input B |

Web Interface Automatic Log-out

You can set up the web interface's automatic log-out timing, requiring re-login by entering the user name and the passwords for security purposes or for the convenience of operation.

To set it up, go to **System > Security > Session Time Out** interface.

| Session Time Out | |
|------------------------|--------------------|
| Session Time Out Value | 9000 (60~14400Sec) |

High Security Mode

High security mode is designed to enhance the security. It employs encryption across various facets, including the communication process, door opening commands, password storage methods, and more.

| |
|----------------------------------|
| High Security Mode |
| Enabled <input type="checkbox"/> |

Important Notes

1. The High Security mode is off by default when you upgrade the device from a version without the mode to one with it. But if you reset the device to its factory settings, the mode is on by default.

2. This mode makes the old version tools incompatible. You need to upgrade them to the following versions or higher to use them.

- PC Manager: 1.2.0.0
- IP Scanner: 2.2.0.0
- Upgrade Tool: 4.1.0.0
- SDMC: 6.0.0.34

3. The supported HTTP format for relay triggering varies depending on whether high secure mode is enabled or disabled.

If the mode is on, the device only accepts the new HTTP formats below for door opening.

- `http://username:password@deviceIP/fcgi/OpenDoor?action=OpenDoor&DoorNum=1`
- `http://deviceIP/fcgi/OpenDoor?action=OpenDoor&DoorNum=1`

If the mode is off, the device can use both the new formats above and the old format below:

- `http://deviceIP/fcgi/do?action=OpenDoor&UserName=username&Password=password&DoorNum=1`

4. It is not allowed to import/export configuration files in tgz. format between a device with the high security mode and another one without it. For assistance with file transfer, please contact Akuvox technical support.

Logs

Access Logs

You can search and check door logs on the device web **Status > Access Log** interface.

Access Log

Save Access Log Enable ☒

Remote Door Log Enabled ☒

Remote Server

Authorization Mode

Token

Token URL

Username

Password

All

Select date

Select date

Name/Code

Search

Export

| | Index | User ID | Name | Code | Door ID | Type | Date | Time | Mode | Status |
|--------------------------|-------|---------|---------|---------|---------|------|------------|----------|--------|--------|
| <input type="checkbox"/> | 1 | Unknown | Unknown | Unknown | | BLE | 2024-05-22 | 08:07:23 | Normal | Failed |
| <input type="checkbox"/> | 2 | Unknown | Unknown | Unknown | | BLE | 2024-05-22 | 08:07:05 | Normal | Failed |

Selected:0/2

Delete

Delete All

Total:2

Prev

1/1

Next

Go To Page

1

Go

- **Save Access Log Enable:** Decide whether to save the door-opening records.
- **Remote Door Log Enabled:** Decide whether to send the door log to a third-party server.
- **Remote Server:** Enter the remote server address.
- **Authorization Mode:** Select from the **None**, **Basic**, **Digest**, and **Token**.
 - **Basic:** You are required to enter the username and password for authentication.
 - **Token:** You are required to enter the token URL, username, and password for authentication.
- **Status:** **Success** and **Failed** options represent successful door accesses and failed door accesses respectively.
- **Time:** Select the specific period of the door logs you want to search, check, or export.
- **Name/Code:** Search the log by the username or the PIN code.
- **Door ID:** Display the door name.

- **Type:** Display the access type such as Card.

Event Logs

The event logs record the key events such as the status change of input, relay, tamper alarm, etc. This helps track the status and changes of the device.

Check event logs on the **Status > Event Log** interface. You can export the log in CSV format.

Event Log

| Type | All x | Time | Start Time ~ End Time | Search | Export ▼ |
|---------------------|-----------------|---|-----------------------|--------|----------|
| Time | Event Type | Status | | | |
| 2024-12-10 15:31:30 | Config Change | Configuration Changed; Operator = admin | | | |
| 2024-12-10 15:11:00 | Config Change | Configuration Changed; Operator = admin | | | |
| 2024-12-10 15:10:53 | Login | Account admin; Success; IP 192.168.35.85 | | | |
| 2024-12-10 15:10:16 | Config Change | Configuration Changed; Operator = admin | | | |
| 2024-12-10 15:10:07 | Password Change | Account admin; Password Changed; Operator = admin | | | |
| 2024-12-10 15:10:07 | Config Change | Configuration Changed; Operator = admin | | | |
| 2024-12-10 15:10:00 | Login | Account admin; Success; IP 192.168.35.85 | | | |
| 2024-12-10 15:09:58 | Login Attempt | Account admin; Failed; IP 192.168.35.85 | | | |
| 2024-12-10 15:09:53 | Login Attempt | Account admin; Failed; IP 192.168.35.85 | | | |
| 2024-12-10 07:08:42 | Upgrade | Firmware upgraded from 103.30.10.111 to 103.30.10.117 | | | |

Integration with Third Party Device

Integration via Wiegand

The access control terminal can be integrated with third-party devices via Wiegand.

To set it up, go to **Device > Wiegand** interface.

Wiegand

| | |
|---------------------------|-------------------------------------|
| Wiegand Display Mode | 8HN ▼ |
| Wiegand Card Reader Mode | Wiegand-26 ▼ |
| Wiegand Transfer Mode | Input ▼ |
| Wiegand Input Clear Time | 5 ▼ |
| Wiegand Input Data Order | Normal ▼ |
| Wiegand Output Data Order | Normal ▼ |
| Wiegand Output CRC Enable | <input checked="" type="checkbox"/> |

- **Wiegand Display Mode:** Select the Wiegand card code format from the provided options.
- **Wiegand Card Reader Mode:** The transmission format should be identical between the access control terminal and the third-party device. It is automatically configured.
- **Wiegand Transfer Mode:**
 - **Input:** The device serves as a receiver.
 - **Output:** The device serves as a sender.
- **Wiegand Input Clear Time:** When the interval of entering passwords exceeds the time. All entered passwords will be cleared.
- **Wiegand Input Data Order:** Set the Wiegand input data sequence between Normal and Reversed. If you select Reversed, then the input card number will be reversed.
- **Wiegand Output Data Order:** Determine the sequence of the card number.
 - **Normal:** The card number is displayed as received.
 - **Reversed:** The order of the card number is reversed.

- **ID Card Output Raw Bytes:** This option is available when Wiegand Transfer Mode is **Output**. Select the output bytes of ID cards between 3 bytes and 4 bytes.
- **Wiegand Output CRC Enable:** It is enabled by default for Wiegand data inspection. Disabling it may lead to integration failure with third-party devices.
- **Wiegand Out Verification:** This feature is for checking the card validity when Output mode is selected. This feature requires you to assign the card code to a user on the **Directory > User** interface.
- **Card Entered Action:** This option is available when Wiegand Transfer Mode is **Output** and Wiegand Out Verification is disabled. You can enter an HTTP command sent to a third-party HTTP server to verify the validity of the card.
Please refer to the HTTP formats: *http://{server ip}/validcard={\$card_sn}*; *http://{server ip}/invalidcard={\$card_sn}*.
Replace {server ip} with the HTTP server IP and {\$card_sn} with the card code.

Note

Click [here](#) to see detailed configuration steps.

Lift Control

The device can be connected to the Akuvox lift controller for the lift control. You can summon the lift to go down to the ground floor when you are granted access through various types of access methods.

To set up the lift control, go to **Device > Lift Control** interface.

Lift Control List

| | |
|-------------------|----------|
| Lift Control List | Akuvox ▼ |
|-------------------|----------|

Akuvox Advance Setting

| | |
|------------|----------------|
| Lift Mode | Choose Floor ▼ |
| Server1 IP | |
| Port | (1~65535) |

Akuvox Action

| | |
|-------------------------------|--|
| User Name | |
| Password | ***** |
| Floor No. Parameter | \$floor |
| URL To Trigger Specific Floor | /fcgi/do?action=OpenDoor&UserName=admin& |
| URL To Trigger All Floors | /fcgi/do?action=OpenAll&UserName=admin& |
| URL To Close All Floors | /fcgi/do?action=CloseAll&UserName=admin& |

- **Lift Control List:** Select Akuvox for integration with the Akuvox lift controller.
- **Server IP:** Enter the IP address of the Akuvox lift controller server.
- **Port:** Enter the port of the Akuvox lift controller server.
- **User Name:** Enter the user name of the lift controller for authentication.
- **Password:** Enter the password of the lift controller for authentication.
- **Floor NO. Parameter:** Enter the Floor number parameter provided by Akuvox.
- **URL To Trigger Specific Floor:** Enter the URL for triggering a specific floor.
- **URL To Trigger All Floors:** Enter the URL for triggering all floors.
- **URL To Close All Floors:** Enter the URL used for closing all floors.

Integration via HTTP API

HTTP API is designed to achieve a network-based integration between the third-party device and the Akuvox intercom device.

To set it up, go to **Setting > HTTP API** interface.

HTTP API

HTTP API Enable

☒

Authorization Mode

Allowlist

▼

Username

admin

Password

••••••••

1st IP

2nd IP

3rd IP

4th IP

5th IP

- **HTTP API Enable:** Enable or disable the HTTP API function for third-party integration. If the function is disabled, any request to initiate the integration will be denied and return HTTP 403 forbidden status.
- **Authorization Mode:** Select among the following options: None, Allowlist, Basic, Digest, and Token for authorization type, which will be explained in detail in the following chart.
- **Username:** Enter the user name when **Basic** or **Digest** authorization mode is selected. The default username is admin.
- **Password:** Enter the password when **Basic** or **Digest** authorization mode is selected. The default password is admin.
- **1st IP-5th IP:** Enter the IP address of the third-party devices when the **Allowlist** authorization is selected for the integration.

Please refer to the following description for the Authentication mode:

| NO. | Authorization Mode | Description |
|-----|--------------------|---|
| 1 | None | No authentication is required for HTTP API as it is only used for demo testing. |
| 2 | Allowlist | If this mode is selected, you are only required to fill in the IP address of the third-party device for the authentication. The allowlist is suitable for operation in the LAN. |
| 3 | Basic | If this mode is selected, you are required to fill in the username and password for the authentication. In the Authorization field of the HTTP request header, use the Base64 encode method to encode of the username and password. |
| 4 | Digest | The password encryption method only supports MD5. MD5(Message-Digest Algorithm) In the Authorization field of HTTP request header: WWW-Authenticate: Digest realm="HTTPAPI",qop="auth,auth-int",nonce="xx", opaque="xx". |
| 5 | Token | This mode is used by Akuvox developers only. |

Power Output Control

The device can serve as a power supply for the external relays.

To set it up, go to **Access Control > Relay** interface.

12V Power Output

Relay ID

RelayA

12v Power Output Enabled

Disabled ▼

- **12v Power Output Enabled:**
 - **Always:** The device can provide continuous power to the third-party device.


- **Security Relay A:** The device can work with the security relay.

Debug

System Log for Debugging

System logs can be used for debugging purposes.

To set it up, go to **System > Maintenance > System Log** interface.



The screenshot shows the 'System Log' configuration interface. It has a title bar 'System Log'. Below it, there are four rows of configuration options:

| Configuration Option | Value / Control |
|---------------------------|---|
| Log Level | 3 (dropdown menu) |
| Export Log | Export button (blue with download icon) |
| Remote System Log Enabled | <input type="checkbox"/> |
| Remote System Server | Empty text input field |

- **Log Level:** Log levels range from 1 to 7. You will be instructed by Akuvox technical staff about the specific log level to be entered for debugging purposes. The default log level is 3. The higher the level is, the more complete the log is.
- **Export Log:** Click the **Export** tab to export the temporary debug log file to a local PC.
- **Remote System Server:** Set the remote server address to receive the device log. The remote server address will be provided by Akuvox technical support.

Remote Debug Server

When the device is having a problem, you can use the remote debug server to access the device log remotely for debugging purposes.

To set it up, go to **System > Maintenance > Remote Debug Server** interface.

Remote Debug Server

Enabled

☐

Connect Status

Disconnected

IP Address

Port

(1024~65535)

- **Connect Status:** Display the remote debug server connection status.
- **IP Address:** Set the remote debug server IP address. Please ask the Akuvox technical team for the server IP address.
- **Port:** Set the remote debug server port.

PCAP for Debugging

PCAP is used to capture the data package going in and out of the devices for debugging and troubleshooting purposes.

To set it up, go to **System > Maintenance > PCAP** interface.

PCAP

Specific Port

(1~65535)

PCAP

Start

Stop

Export

PCAP Auto Refresh Enabled

☐

- **Specific Port:** Select the specific ports from 1-65535 so that only the data packet from the specific port can be captured. You can leave the field blank by default.
- **PCAP:** Click the **Start** tab and **Stop** tab to capture a certain range of data packets before clicking the **Export** tab to export the data packets to your Local PC.
- **PCAP Auto Refresh Enabled:** When enabled, the PCAP will continue to capture data packets even after the data packets reach their 50M maximum in capacity. When disabled, the PCAP will stop data packet capturing when the data packets captured reach the maximum capturing capacity of 1MB.

Ping

The device allows you to verify the accessibility of the target server.

To set it up, go to the **System > Maintenance > Ping** interface.

Ping

Cloud Server

Verify the network address accessibi...

You can enter the domain name or IP you want to detect in the drop-down box.

- **Cloud Server:** The server to be verified.
- **Verify the network address accessibility:** The service type.

Backup

You can import or export encrypted configuration files to your Local PC for backup.

Go to **System > Maintenance > Others** interface.

| Others | |
|-------------|---|
| Config File | <div><div>Import</div><div>Export (Encrypted)</div></div> |

Firmware Upgrade

Akuvox devices can be upgraded on the device web interface.

To upgrade the device, go to **System > Upgrade** interface.

Basic

| | |
|---|--|
| Firmware Version | 103.30.10.117 |
| Hardware Version | 103.0.15.0.0.0.0.0 |
| Upgrade |  Import |
| Reset Configuration to Default State(Except Data) |  Reset |
| Reset To Factory Setting |  Reset |
| Reboot |  Reboot |

Note


The file should be in .rom format.

Auto-provisioning via Configuration File

Provisioning Principle

Auto-provisioning is a feature used to configure or upgrade devices in batch via third-party servers. **DHCP, PNP, TFTP, FTP, and HTTPS** are the protocols used by the Akuvox devices to access the URL of the address of the third-party server which stores configuration files and firmware, which will then be used to update the firmware and the corresponding parameters on the device.

Please see the flow chart below:



Introduction to the Configuration Files for Auto-Provisioning

Configuration files for auto-provisioning come in two formats: general configuration files and MAC-based configuration files.

Differences:

- **General Configuration Provisioning:**

A general configuration file is stored on a server, allowing all related devices to download the same file to update parameters.

- **MAC-Based Configuration Provisioning:**

MAC-based configuration files are specific to individual devices, identified by their unique MAC addresses. Files named with the device's MAC address will be matched automatically before downloading for provisioning.

Note

- Configuration files must be in CFG format.
- The name of the general configuration file for batch provisioning varies by model.
- The MAC-based configuration file is named after its MAC address.
- Devices will first access general configuration files before the MAC-based ones if both types are available.

You may click [here](#) to see the detailed format and steps.

Autop Schedule

Akuvox provides you with different AutoP methods that enable the device to perform provisioning for itself according to the schedule.

To set it up, go to **System > Auto Provisioning > Automatic Autop** interface.

Automatic Autop

| | |
|-----------------------|---------------|
| Mode | Power On ▼ |
| Schedule | Sunday ▼ |
| | 22 (0~23Hour) |
| | 0 (0~59Min) |
| Clear MD5 | Clear |
| Export Autop Template | Export |

- **Mode:**

- **Power On:** The device will perform Autop every time it boots up.
- **Repeatedly:** The device will perform Autop according to the schedule you set up.
- **Power On + Repeatedly:** Combine **Power On** mode and **Repeatedly** mode that will enable the device to perform Autop every time it boots up or according to the schedule you set up.
- **Hourly Repeat:** The device will perform Autop every hour.

Static Provisioning

You can manually set up a specific server URL for downloading the firmware or configuration file. If an auto-provision schedule is set up, the device will perform the auto-provisioning at a specific time according to the auto provision schedule you set up. In addition, TFTP, FTP, HTTP, and HTTPS are the protocols that can be used for upgrading the device firmware and configuration.


To set it up, download the template on **System > Auto Provisioning > Automatic Autop** first.

Automatic Autop

| | |
|-----------------------|---------------|
| Mode | Power On ▼ |
| Schedule | Sunday ▼ |
| | 22 (0~23Hour) |
| | 0 (0~59Min) |
| Clear MD5 | Clear |
| Export Autop Template | Export |

Set up the Autop server on **System > Auto Provisioning > Manual Autop** interface.

Manual Autop

| | |
|--|--------------------------|
| URL | <input type="text"/> |
| Username | <input type="text"/> |
| Password | <input type="password"/> |
| Common AES Key | <input type="password"/> |
| AES Key(MAC) | <input type="password"/> |
|  AutoP Immediately | |

- **URL:** Specify the TFTP, HTTP, HTTPS, or FTP server address for the provisioning.
- **Username:** Enter the username if the server needs a username to be accessed.
- **Password:** Enter the password if the server needs a password to be accessed.
- **Common AES Key:** It is used for the device to decipher general Autop configuration files.
- **AES Key (MAC):** It is used for the device to decipher the MAC-based Autop configuration file.

Note


- AES as one type of encryption should be configured only when the config file is encrypted with AES.
- Server Address Format:
 - TFTP: tftp://192.168.0.19/
 - FTP: ftp://192.168.0.19/(allows anonymous login)
ftp://username:password@192.168.0.19/(requires a user name and password)
 - HTTP: http://192.168.0.19/(use the default port 80)
http://192.168.0.19:8080/(use other ports, such as 8080)
 - HTTPS: https://192.168.0.19/(use the default port 443)

Tip

Akuvox does not provide user specified server. Please prepare TFTP/FTP/HTTP/HTTPS server by yourself.

DHCP Provisioning

Auto-provisioning URL can also be obtained using the DHCP option which allows the device to send a request to a DHCP server for a specific DHCP option code. If you want to use **Custom Option** as defined by users with option codes ranging from 128-255, you are required to configure DHCP Custom Option on the web interface.



Note

The Custom Option type must be a string. The value is the URL of the TFTP server.

To set up DHCP Autop with **Power On** mode, go to the web **System > Auto Provisioning > Automatic Autop** interface.

Automatic Autop ⓘ

| | |
|-----------------------|---------------|
| Mode | Power On ▼ ⓘ |
| Schedule | Sunday ▼ ⓘ |
| | 22 (0~23Hour) |
| | 0 (0~59Min) |
| Export Autop Template | Export ⓘ |
| Clear MD5 | Clear ⓘ |

To set up the DHCP Option, scroll to the **DHCP Option** section.

DHCP Option

| | | |
|---------------|-------------------------------|-----------|
| Custom Option | <input type="text" value=""/> | (128~254) |
|---------------|-------------------------------|-----------|

(DHCP option 66/43 is enabled by default.)

- **Custom Option:** Enter the DHCP code that matches with corresponding URL so that the device will find the configuration file server for the configuration or upgrading.
- **DHCP Option 43:** If the device does not get a URL from DHCP Option 66, it will automatically use DHCP Option 43. This is done within the software and the user does not need to specify this. To make it work, you need to configure the DHCP server for option 43 with the upgrade server URL in it.
- **DHCP Option 66:** If none of the above is set, the device will automatically use DHCP Option 66 to get the upgrade server URL. This is done within the software and the user does not need to specify this. To make it work, you need to configure the DHCP server for option 66 with the upgrade server URL in it.

Password Modification

Modify Device Web Password

You can modify the device web password for both the administrator account and the user account.

To set it up, go to **System > Security > Web Password Modify** interface.

Web Password Modify

| | | |
|----------|--|---------------------------------|
| Username | admin | Change Password |
| | Modify Security Question | |

Click **Change Password** to modify the password.

Web Password Modify

| | | |
|----------|-------|---------------------------------|
| Username | admin | Change Password |
|----------|-------|---------------------------------|

Change Password

The password must be at least eight characters long and contains at least one uppercase letter, one lowercase letter, and one digit.

| | |
|------------------|--------------------------|
| Username | admin |
| Old Password | <input type="password"/> |
| New Password | <input type="password"/> |
| Confirm Password | <input type="password"/> |

[Cancel](#) [Change](#)

To enable or disable the user account, scroll to the **Account Status** section. The default password for the user account is **user**.

| Account Status | |
|----------------|--------------------------|
| admin | Enabled |
| user | <input type="checkbox"/> |

Modify Security Questions

Security questions allow you to reset the web password if you forget it. After setting up the security questions, you can click "Forget Password" on the login interface, enter the answers, and a password reset window will pop up.

If you do not set up the security questions, clicking "Answer security questions" will prompt you to "Please contact your service provider".

To set it up, go to the **System > Security > Web Password Modify** interface.

Web Password Modify

Username Change Password

Modify Security Question

You need to first enter the right password for verification and then set up the security questions.

Web Password Modify

Username Change Password

Please set up your security questions.

Question 1

Answer

Question 2

Answer

Question 3

Answer

Ignore Submit

System Reboot and Reset

Reboot

Reboot the device on the web **System > Upgrade** interface.

Basic

| | |
|---|--|
| Firmware Version | 103.30.10.117 |
| Hardware Version | 103.0.15.0.0.0.0.0 |
| Upgrade |  Import |
| Reset Configuration to Default State(Except Data) |  Reset |
| Reset To Factory Setting |  Reset |
| Reboot |  Reboot |

To set up the device restart schedule, go to **System > Auto Provisioning > Reboot Schedule** interface.

Reboot Schedule

Mode

☐

Schedule

Every Day

▼

0

(0~23Hour)

Reset

The device provides two reset options:

- **Reset to Factory Setting:** Reset all data to the factory default.
- **Reset Configuration to Default State(Except Data):** Retain the user data such as the RF cards, face data, schedules, and call logs.

Reset the device on **System > Upgrade** interface.

Basic

| | |
|---|--|
| Firmware Version | 103.30.10.117 |
| Hardware Version | 103.0.15.0.0.0.0.0 |
| Upgrade |  Import |
| Reset Configuration to Default State(Except Data) |  Reset |
| Reset To Factory Setting |  Reset |
| Reboot |  Reboot |

You can also reset the device by long pressing the **Reset** button on the back of the device.

