

Introduction

- Connect your IP phone to a Bluetooth headset
- Connect your IP phone to a wireless network
- Use only one dongle for both functions (Bluetooth & Wi-Fi)

Assembling the USB Dongle

Insert the USB Dongle to the USB port on the IP phone.

Connecting to the Wireless Network


- 1.Assemble the USB Dongle.
- 2.The LCD screen prompts "WIFI adapter plugged in. Start scan now?"
- 3.Press the **OK** soft key.
- 4.The phone saves and scans automatically.
- 5.Select **X Available Network(s)**.
- 6.Select the desired wireless network and then press the **Connect** soft key.
- 7.(Optional.) Enter its password in the Password field.
- 8.Press the **Connect** soft key.
- 9.Once the connection completes successfully, the icon ✓ appears after the SSID.

Connecting to the Bluetooth Headset

- 1.Turn on the Bluetooth headset.
- 2.Long press the multifunction key on the Bluetooth headset until the indicator LED alternately flashes red and blue. The Bluetooth headset is in pairing mode.
- 3.Assemble the USB Dongle.
- 4.The LCD screen prompts "WIFI adapter plugged in. Start scan now?"
- 5.Press the **Cancel** soft key.
- 6.Find Menu then navigate as follows: Menu→Settings→Basic Setting→Bluetooth
- 7.Turn on and press the **Save** soft key to save the configuration.
- 8.Press the **Scan** soft key.
- 9.The phone starts searching for Bluetooth headsets.
- 10.Choose the desired Bluetooth Device from the list and press the **Connect** soft key.
- 11.If the Bluetooth Device is connected/paired successfully, you will see the "Connect Success!" and successfully connected icon ✓.

Tel: 0086-25-84658050 | Fax: 0086-25-84658319
Mail: support@hitek.com | Web: www.hitek.com
Add: 5th Floor, 1st Building, Huashen Tech Park, No.10 Huashenmiao, Yuhuatai District,
Nanjing, 210012, China
Copyright: ©2022 Nanjing Hanlong Technology Co., Ltd. All rights reserved.

IP Phone



WFBT60 User Guide